

Jeep Renegade Ceiling net install

Time 20 minutes

Tools: 5mm allen wrench, phillips screwdriver, small flat blade or panel removal tool

1. Carefully remove round cover from upper 1/4 panel to the rear of the small side window. Remove OE 5mm screw and replace with longer screw, square ring anchor and washer set supplied. The washer may be painted with textured undercoating paint as shown if desired.



2. Install front straps to OE handles above rear seat.
-



3. Each strap has adjustability to drop down net, place soft items between net and headliner and pull straps to snug up as taut as desired, paying attention as to not put sharp edges that could dent or damage headliner. Jacket, sleeping bags, and maps secure well and can place your own carabineers to further

anchor item in place.



4. Tuck excess strap back into buckle opening by the push tab, wrap around through the webbing loop on top of the push tab and tuck remained inside and pack into the loop. Enjoy your ceiling net. The rear barrier net uses the same mounts just installed and can be run in conjunction with the ceiling net. Also see our other Renegade products at raingler.com

